TOP AND CONSOLE PARTS

ELECTRIC DRYER

For Model: 3RAWZ481EML1

(Pewter)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: 3RAWZ481EML1

(Pewter)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8545902	Label, Wiring Diagram
	8543078	Use & Care Guide
	8563878	Installation Instructions
	8315975	Installation & User Guide
2	3980096	Top
3	8543289	Harness, Main
4	3979740	Panel, Console (Includes Illus. 13, 14 15, 17, 18 & 19)
5	3394427	Clip, Harness
6	3980123	Bracket, Console
7	353424	Connector, Sensor
8	94614	Terminal
9	3936144	Plug, Terminal
10	94613	Terminal
11	3390647	Screw, 8−18 x 1/2
12	488886	Screw, 8−18 x 1/2
13	3980121	Button, Push−To−Start
14	3979738	Bracket, Timer
15	3979743	Bracket, Switch Mounting
16	8281225	Screw, 8−18 x 1/2
17	8543319	Medallion
18	3956540	Console, Center
19	3400238	Screw, 2−28 x 1/2
20	3980205	Timer
21	3951198	Fuse
22	3390646	Screw, 8−18 x 5/16
23	3980421	Spacer Plate (Timer)
24	8316076	Switch, Wrinkle Guard
25	8522378	Buzzer, Mini
26	8562100	Switch, Push−To−Start
27	3399642	Switch, Temperature
28	8543291	Harness, Console
29	3347243	Connector, 6−Circuit
30	3397269	Connector, Timer
31	3401144	Connector (PTS Relay)
32	692997	Connector
33	3980218	Knob, Timer Assembly
34	3980129	Knob, Control (2)
35	3980339	Shield, Drip

CABINET PARTS

For Model: 3RAWZ481EML1

(Pewter)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: 3RAWZ481EML1

(Pewter)

Illus. No.	Part No.	DESCRIPTION
1	8317342	Cover, Terminal Block
2	98139	Screw, 8−32 x 5/16
3	697776	Screw, 10−32 x 5/8 (Ground)
4	3397659	Block, Terminal
5	8318457	Switch, Broken Belt
6	8521947	Dry Rack (Top)
7	8519216	Panel, Side (L.H.)
8	3392100	Foot, Dryer
	279810	Foot − Optional (Extended Length Package Of 2) (Not Included)
9	660658	Clamp, Motor (2)
10	3387374	Spring, Idler
11	3389420	Retainer, Idler
12	3979261	Plug, Multivent
13	3388672	Pulley Assembly
14	279318	Terminal, Brass & Tinned (3) (Includes Illus. 33)
15	8066120	Lever, Snap Switch
16	3394081	Wire, Belt Switch
17	8528076	Sound Panel
18	233520	Washer, Thrust
19	8543119	Wire, Jumper (Includes Illus. #41)
20	690997	Tri Ring
21	8066115	Cover−Plate
22	8529053	Ramp, Door
23	8521961	Dry Rack Support
24	8519217	Panel, Side (R.H.)
25	8521950	Dry Rack Assembly
26	3393657	Restrainer, Belt
27	3404470	Motor, Assembly 50 HZ.
29	3402548	Pulley 50 HZ.
30	3387610	Belt, Drive
31	8541503	Kit, Stack Assembly
32	3387118	Bracket, Motor
33	279393	Terminal Block Screw Kit (For Terminal Block)
34	49026	4" − 90° Elbow
35	8316644	Clip, Strain Relief
36	3395532	Exhaust Pipe & Bracket
37	3395534	Exhaust Pipe (Short)
38	3395535	Exhaust Pipe (Long)
39	3388674	Idler Bracket
41	8541808	Switch, Door
42	3400934	Screw, 6−20 x 1 1/16
43	3390647	Screw, 8−18 x 1/2
44	3387242	Seal, Front Panel
45	3393008	Screw, 10−16 x 1/2
46	8519459	Clip, Toe Panel
47	340025	Wire, Ground
50	8519207	Base, Cabinet
51	8562170	Front Panel
52	696144	Strike, Door (2)
53	90767	Screw, 8−18 x 3/8
56	8519273	Bracket, Control
61	3980095	Toe, Panel
62	8543118	Panel, Rear
63	692400	Nut, Push−In
64	3400097	Screw, 10−24 x 3/8

Optional Parts Not Included

Dryer Exhaust Kit (For Side & Bottom Venting)

66	279969	Grey

BULKHEAD PARTS

For Model: 3RAWZ481EML1

(Pewter)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: 3RAWZ481EML1

(Pewter)

Illus. No.	Part No.	DESCRIPTION
1	3399508	Shaft, R.H. Thread
2	3390647	Screw, 8−18 x 1/2
3	3394984	Door, Lint Screen
4	98139	Screw, 8−32 x 5/16
5	697354	Air Duct Assembly
6	697813	Seal, Outlet Housing
7	697814	Seal, Drum Front
8	3359452	Nut,3/8 x 16(R.H.)
9	8066086	Drum Hole Plug
10	696302	Shield, Exhaust
12	3388229	Clip, Exhaust Pipe
13	3390646	Screw, 8−18 x 5/16
14	3387749	Heater Element
15	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)
16	3387709	Nut, 3/8−16 (L.H.)
17	3387809	Bulkhead, Rear
18	3387459	Washer, Support
19	3399509	Shaft, L.H. Thread
20	690997	Ring, Tri
21	8536973	Roller, Support
22	3402715	Exhaust Pipe
23	3394985	Housing, Outlet
24	8529007	Plug, Rear Bulkhead
25	8543082	Complete Drum Assembly
26	97787	Screw, 11−16 x 3/4
27	697694	Seal, Drum
28	695240	Screw, 8−18 x 1/2
29	90767	Screw, 8−18 x 3/8
30	8519221	Channel Bracket, Rear Bulkhead (2)
31	8519275	Bracket, Upper Rear Bulkhead
32	3400826	Screw, 8−18 x 3/4
34	3357011	Screw, 10−16 x 1/2
37	697772	Wheel, Blower
39	3394986	Spring, Lint Screen Door
42	3387137	Thermistor
44	8544362	Housing, Blower
45	8066168	Lint Duct Assembly
46	3392537	Heater Box
47	3977394	Thermal Cut−Off (Includes Illus. 48)
48	3390291	Thermostat 250°F (121°C)
50	8066099	Bracket, Heater Box
51	3387230	Screw, 10−16 x 1
53	697693	Baffle, Drum
54	8519245	Bulkhead, Front
58	8299979	Grill, Outlet
59	3392519	Thermal Fuse
60	697770	Seal, Cover Plate
64	8066170	Lint, Screen

DOOR PARTS

For Model: 3RAWZ481EML1

(Pewter)



Illus. No.	Part No.	DESCRIPTION
1	8563855	Plug, Strip
2	8519361	Door Hinge Assembly
3	3980214	Cover, Door Hinge
4	9742177	Screw, 8−18 x 5/8
5	342043	Screw, 10−32 x 3/8
6	8519336	Pad, Door Handle
7	3980212	Handle, Door
8	3400224	Screw, 1/4−20 x 1/2
9	8519374	Plug, Door Handle (2)
10	8519309	Door Assembly (Inner) (Includes Illus. 14)
11	355515	Screw, 8−18 x 11/16
12	3980213	Door, Outer
13	8545879	Window
14	3389441	Door Catch Assembly

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Model: 3RAWZ481EML1

(Pewter)

Illus. No.	Part No.	DESCRIPTION
		PAINT, TOUCH−UP (1/2oz.)
	4396174	Pewter
		PAINT, PRESSURIZED SPRAY (12 oz.)
	4396175	Pewter
	350938	Primer, Gray
		ACCESSORY PARTS
	8529894	Hold Down Kit